

CORE DRILL

The **E2181A** core drill is a portable unit with many features that will make it attractive to you. The unit comes with a 14" x 19" rugged aluminum base. The base also has four leveling screws so that you can precisely level the drill on uneven surfaces. Attached to the base are two durable 5" dia wheels for ease of movement from one place to the other. The column that the drill is attached to a 42" long steel construction and bolts securely to the base. The motor moves on a gear and rack system. The motor can easily be removed using the quick disconnect lever. The drill handles a maximum 10" dia. bit with an optional spacer kit for larger bits. The **E2183C** Vacuum Assembly attaches to the base and provides a vacuum so that the base gets pulled down to the surface that you are drilling.



MODELS	DESCRIPTION
E2181A	ELECTRIC CORE DRILL, 115V / 60 Hz
E2181B	ELECTRIC CORE DRILL W/ VAC PAD, 230V / 60 Hz

ACCESSORIES	DESCRIPTION
E2183C	VACUUM ASSEMBLY

CORE DRILL, 8 HP & 5 HP

This core drill is a portable model that is available in either gasoline (8 hp) or electric (5 hp) powered versions. This drill can obtain cores up to 8" in diameter and has a feed length of 22". The drill uses diamond core bits to quickly take clean, accurate concrete or bituminous cores from roads and runways. The drill is transportable in a pickup truck or van and is designed for one person operation. The drill is mounted on a ball screw feed and is set at a convenient height for operator use.



MODELS	DESCRIPTION	STANDARDS
E2201	CORE DRILL, 8 HP, GAS	ASTM C-42 / AASHTO T-24
E2203	CORE DRILL, 5 HP, 3 PHASE, 208-230V / 60 Hz	
E2204	CORE DRILL, 5 HP, 3 PHASE, 230V / 50 Hz	

ACCESSORIES	DESCRIPTION
E2211	SHAFT EXTENSION 9"
E2212	WATER PUMP, 115V / 60 Hz
E2212E	WATER PUMP, 220V / 50 Hz
E2213	DIAMOND BIT
E2214	EXTRA WHEEL
E2215	HORIZONTAL ATTACHMENT (ELECTRIC ONLY)
E2216	STRAP WRENCH
E2217	WATER TANK, 4 GAL, W/ HAND PUMP
E2218	WATER SAVING ASSEMBLY