

WET WASHING SIEVES**G1951 & G1958**

Used for wet sieving of soil, cement and fine aggregates. In accordance with ASTM and AASHTO requirements, sieves have deep frames to prevent loss of fines when washing and have a brass frame and bronze or stainless steel mesh (see models for description). The **G1968** is the Corps of Engineers type wet washing assembly. It has a capacity of 10 to 12 lbs. and includes a 12" dia. brass frame with a #200 mesh detachable screen with a coarser mesh backing at the bottom. The **G1968** is 10" deep and is supplied with an overload screen at the midpoint. A wet washing attachment (**G1969**) is also available. The attachment provides a fine spray at controlled pressure for efficient washing and protection of fine sieve cloth. The attachment consists of a spray nozzle, gauge, fittings and valve with NPT pipe thread.

**G1968****G1969**

MODELS	DESCRIPTION	DIA.	MESH	HEIGHT	STANDARDS
G1951	WET WASHING SIEVE, BRASS FRAME	3"	#200 BRASS	3"	ASTM C-92, C-115 C-430, C-618, C-786 AASHTO M-150, T-98, T-192
G1955	WET WASHING SIEVE, BRASS FRAME	8"	#200 BRASS	4"	
G1955A	WET WASHING SIEVE, BRASS FRAME	8"	#200 ST. STL.	4"	
G1955C	WET WASHING SIEVE, BRASS FRAME	8"	#200 BRASS	6"	
G1956	WET WASHING SIEVE, BRASS FRAME W/ BRASS BACK-UP	8"	#200 ST. STL.	4"	
G1956A	WET WASHING SIEVE, BRASS FRAME W/ ST. STL. BACK-UP	8"	#200 ST. STL.	4"	
G1957	WET WASHING SIEVE, BRASS FRAME	8"	#200 BRASS	8"	
G1957A	WET WASHING SIEVE, BRASS FRAME	8"	#200 ST. STL.	8"	
G1958	WET WASHING SIEVE, BRASS FRAME W/ BRASS BACK-UP	8"	#200 BRASS	8"	
G1958A	WET WASHING SIEVE, BRASS FRAME W/ ST. STL. BACK-UP	8"	#200 ST. STL.	8"	
G1959	WET WASHING SIEVE, BRASS FRAME	2"	#325 ST. STL.	3-5/8"	
G1960	WET WASHING SIEVE, BRASS FRAME	12"	#200 ST. STL.	4"	
G1960B	WET WASHING SIEVE, BRASS FRAME W/ ST. STL. BACK-UP	12"	#200 ST. STL.	4"	
G1968	WET WASHING SIEVE, BRASS FRAME CORPS OF ENGINEERS TYPE	12"	#200 BRASS	12"	

ACCESSORIES**DESCRIPTION**

G1969	WET WASHING SIEVE APPARATUS
--------------	-----------------------------

PORTABLE SCREEN SET

The **G2051** Portable Screen Set is used for sieving coarse aggregate in the field. The 12" screen pan has handles and the collector pan has rockers. The set is furnished with interchangeable screen. Includes 3" (76.1mm), 2" (50.8mm), 1-1/2" (38.1mm), 1" (25.4mm), 3/4" (19mm) 1/2" (12.7mm), 3/8" (9.51mm), and #4 ASTM interchangeable screens. Screens are held in place by a locking device and can be clamped into the frame for easy carrying and storage.



MODELS	DESCRIPTION
G2051	PORTABLE SCREEN SET

ACCESSORIES	DESCRIPTION
G2052	EXTRA SCREEN, 3"
G2053	EXTRA SCREEN, 2"
G2054	EXTRA SCREEN, 1-1/2"
G2055	EXTRA SCREEN, 1"
G2056	EXTRA SCREEN, 3/4"
G2057	EXTRA SCREEN, 1/2"
G2058	EXTRA SCREEN, 3/8"
G2059	EXTRA SCREEN, #4